



MCEGold® Desktop License USB Key Installation/Setup Instructions

1. Install the MCEGold software.
Note: If you are sharing data with MCE_{MAX} test equipment make sure you have the same version installed on both computers.
2. Restart the computer as instructed at the end of the installation.
3. Insert the MCEGold USB Key into any USB port on the computer. Wait for the device driver software to install.
4. Once the device driver software is installed successfully, you may open the MCEGold application.
 - MCEGold will open, but a TEST button **will not** be available on the icon toolbar.

Part #: ADP-SRB02984-USB

Description: Software, MCEGold Desktop License Key

PD-DOC-001