



Electric Motor Testing Tip of the Week

revolutionizing *electrical* reliability

July 16, 2007

Optimize Your Access™ Database Performance

It is recommended that you periodically compact and repair your Access™ database to maintain optimum performance and data integrity. The WinVis software will prompt you to do this on a regular basis, but depending on your testing schedule, it may need to be done as often as once a week.

If you are running a Network Version of the WinVis software, it is recommended that you download the database to your local drive (C:) and perform the operation there, then upload it back to the place it resides on the network drive.

For instructions on how to compact and repair your database see [Application Note 0702 Compact and Repair the WinVis Database](#).

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA mug or hat if we publish it! Contact Lou at 813-621-6463 ext. 126 or lou@pdma.com.