



Electric Motor Testing Tip of the Week

revolutionizing *electrical* reliability

July 7, 2008

MCEGold Message Center

The Message Center, a feature of the MCEGold software, provides us with a well organized file system for all notes regarding each specific asset. As users we enter diagnostic notes into the Message Center to address data analysis and other pertinent bits of information.

A good way to quickly know which specific test the note belongs to is to enter the Time and Data stamps of the test on the subject line of the message when composing a note. The Time/Date stamp can be found on the first two rows of the Test History, as shown below.

Test Date	3/25/2008	6/25/2008
Test Time	1:21:47PM	10:27:05 AM

A note written for the first test above would have "3/25/2008 1:21:47 PM" on the subject line. There is no need to include the test type on the subject line. The test type can be selected from the drop down list after selecting the Asset Section.

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA mug or hat if we publish it! Contact Lou at 813-621-6463 ext. 126 or lou@pdma.com.

Copyright 2007 PdMA Corporation. All rights reserved. The PdMA Tip of the Week is produced by PdMA. PdMA shall not be liable for any errors or delays in the content, or for any actions taken in reliance thereon.