



Electric Motor Testing Tip of the Week

revolutionizing *electrical* reliability

October 29, 2007

How to Extend Battery Life

Although the P series tester battery does not develop a charge memory, its charging capacity will decrease over time with repeated use. To minimize this effect, and extend the useful life of the battery, it is recommended that the battery periodically be put through a discharge cycle. The charger included with the tester has a button labeled "DISCHARGE" which will completely discharge the battery before fully recharging it. It is also recommended to run the battery through this cycle if it has been sitting, unused for more than thirty days.

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA mug or hat if we publish it! Contact Lou at 813-621-6463 ext. 126 or lou@pdma.com.

Copyright 2007 PdMA Corporation. All rights reserved. The PdMA Tip of the Week is produced by PdMA. PdMA shall not be liable for any errors or delays in the content, or for any actions taken in reliance thereon.