



# Tip Of The Week

---

**November 14, 2011**

## Avoid Useless Data

Running an EMAX Auto test is the fastest and easiest way to perform multiple online tests at one time. However, prior to collecting data it is important to know that you are connected to the circuit correctly and at the proper location. Collecting erroneous data consumes time and money, causes rework and disorganization, and debilitates data trending. For those experiencing issues as such, it is recommended to perform an individual Power test (0.17 seconds) to verify your data collection location and connection prior to performing the EMAX Auto test. For more information on the MCEGold software and testing, tutorials, and brochures visit <http://www.pdma.com/PdMA-MCEGold.php>.

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA mug or hat if we publish it! Contact Lou at 813-621-6463 ext. 126 or [lou@pdma.com](mailto:lou@pdma.com).

Copyright 2011 PdMA Corporation. All rights reserved. The PdMA Tip of the Week is produced by PdMA. PdMA shall not be liable for any errors or delays in the content, or for any actions taken in reliance thereon.