



Tip Of The Week

January 26, 2009

No Spell Checker? Try This

Many times the question comes up about how to check the spelling of text when there isn't a spelling check function available. This can easily be solved by typing the text in a word processor, such as Microsoft Word, to perform spelling check and editing. Then using the standard Windows convention copy the text by highlighting it and pressing Ctrl+C. Finally paste the text into the desired text box by clicking in the text box and pressing Ctrl+V.

This technique is especially useful when entering comments in the MCEGold Detailed Report. Highlight the area on the Detailed Report layout where you want to add the comment and select the Edit-Comment tab in the right hand column to open the text area. Paste the comment into the text area. Using the copy (Ctrl+C) and paste (Ctrl+V) hot keys saves the time and effort involved in having to retype the comment.

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA mug or hat if we publish it! Contact Lou at 813-621-6463 ext. 126 or lou@pdma.com.

Copyright 2009 PdMA Corporation. All rights reserved. The PdMA Tip of the Week is produced by PdMA. PdMA shall not be liable for any errors or delays in the content, or for any actions taken in reliance thereon.