



A Leader in Electric Motor Testing

Tip Of The Week

February 2, 2015

Utilize the MCEGold[®] Tools Available

As asset reliability is of great importance to the success of production uptime, when using the MCEGold program for motor testing several tools are provided in addition to data collection that help you strive for excellence within your program.

The Site Condition tool provides a condition snap-shot of your entire motor database along with some basic statistical and last test date information. You can quickly determine assets that have not been tested, assets that have been tested without a condition assigned, and assets that have been assigned to each condition. Using the Site Condition can assist in quickly determining and prioritizing areas of focus and can also be a great starting point to creating a site WatchList, which is another tool that will assist in focusing your attention on a list of specified assets. The Site Condition allows you to select assets from the condition section you are viewing and paste them directly into the WatchList or route of your choice.

By utilizing these tools you can turn your motor testing program from an uncontrolled data collecting initiative to a well communicated and effective site predictive maintenance program that strives for excellence.

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA[®] mug or hat if we publish it! Contact Lou at 813-621-6463 ext. 126 or lou@pdma.com.

Copyright 2014 PdMA[®] Corporation. All rights reserved. The PdMA Tip of the Week is produced by PdMA. PdMA shall not be liable for any errors or delays in the content, or for any actions taken in reliance thereon.