



# Tip Of The Week

**June 22, 2009**

## Where is my Motor?

Testing motors from the MCC is ideal to give a complete health assessment of the power circuit and motor. If the testing indicates an open circuit, a visual inspection of the motor is recommended. If you send data indicating an open circuit to our technical support department they will ask you to verify that the motor is connected. Don't be surprised if your visual inspection results in your comment, "Where is my motor?"

So, if you have an open circuit indication, before sending the data in for review make sure your motor has not been removed for service.

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA mug or hat if we publish it! Contact Lou at 813-621-6463 ext. 126 or [lou@pdma.com](mailto:lou@pdma.com).

Copyright 2009 PdMA Corporation. All rights reserved. The PdMA Tip of the Week is produced by PdMA. PdMA shall not be liable for any errors or delays in the content, or for any actions taken in reliance thereon.