## **TECHNOTE 2201-S10**

## ISSUED

May2022

## SUBJECT

Release of MCEGold  $^{\textcircled{R}}$  3.1.2 SP5 Stand Alone for Windows 10.

## DESCRIPTION

MCEGold 3.1.2 SP5 Stand Alone is an upgrade from MCEGold 3.1.2 SP4. The upgrade includes the ability to view temperatures in °C or °F, DC motor Word Report Templates, Zoom selection for graphs in Word Reports, and additional improvements including X & Y axis numbering, Detailed Report Enhancements, In-Rush/ Start-Up Peak, and Speed Forwarding.

## NOTES

- MCEGold 3.1.2 SP5 is *only* compatible with Windows 10 and M-Series testers.

- Windows 7 users - DO NOT TRY TO UPDATE to MCEGold 3.1.2 SP5. Windows 7 compatibility ended with MCEGold 3.1.2 SP2. If you do try to update, MCEGold will become inoperable.

- Upgrading from a version prior to MCEGold 3.1.2 requires a new license key. Contact PdMA (813-621-6463 ext. 251) for a new license key.

- MCEGold Word Add-in is only compatible with MS Word 2007 and 2013. MCEGold Word Add-in is NOT compatible with MS Word 2010. Templates created with other versions of MS Word may not be functional and may cause conflicts with the MCEGold software.

- MCEGold 3.1.2 SP5 requires that Word Add-in be uninstalled prior to MCEGold 3.1.2 SP5 installation or upgrade.

- MCEGold 3.1.2 SP5 requires that all SQL versions older than 2017 be uninstalled prior to MCEGold 3.1.2 SP5 installation or upgrade.

- To ensure application accessibility, the default installation location has been set to C:\PdMA Corporation.

- Databases attached to MCEGold 3.1.2 SP5 must be from MCEGold 3.0.3 SP2 or later and once updated with MCEGold 3.1.2 SP5 *will not* be compatible with older versions of MCEGold.

- Please make sure you allow sufficient time to update your database. Depending on the size of your database, updates may take an hour or longer.

- Assets opened with MCEGold 3.1.2 SP5 *will not* be compatible with older versions of MCEGold.

- If during installation you receive a message telling you "SQL Server System CLR Types requires the .Net Framework", contact tech support for assistance.

- If you have any questions, please contact PdMA Technical Support (813-621-6463 ext. 251).

### **Minimum Requirements**

Computer	Dell Latitude 5420 Laptop*
Processor	11th Generation Intel Core i5- 1135G7 (4 Core, 8M cache, base 2.4 GHz, up to 4.2 GHz)
Resolution	14" FHD (1920x1080)
Operating System	Microsoft <sup>®</sup> Windows 10 (64 bit)
Memory	8.0+ G RAM
Ports/Drives	(1) USB Port in Rear or Side
Hard Disk	30G Available

\* Original Windows 10 model shipped with PdMA testers. It is not compatible with Windows 7. Using any other computer manufacturer in conjunction with the PdMA software may result in erratic computer behavior; not limited to but including:

Power Management Issues

- Lock-up
- Communication Port Malfunction
- Driver Incompatibility
- Display Errors
- SQL Database IncompatibilityNetwork Synchronization Issues

# PREPARE FOR MCEGOLD 3.1.2 SP5 INSTALLATION

NOTE: If you have MCEGold 3.1.2 or later follow the instructions in *Upgrading From MCEGold 3.1.2 or Later* on page 3.

If you have any version prior to MCEGold 3.1.2 a full uninstall is required before installing version 3.1.2 SP5. See *Upgrading From a Version Prior to MCEGold* 3.1.2.

## Upgrading From a Version Prior to MCEGold 3.1.2

Upgrading from a version prior to MCEGold 3.1.2 requires a new license key. Contact PdMA (813-621-6463 ext. 251) for a new license key.

#### Backup

Before beginning the MCEGold uninstall, copy the Emaxprb.xml file only (not the folder) and the complete Templates folder to a safe location and make note of the location.

The default location for the files is listed below, however you may have chosen a different location during the original installation.

C:\PdMA Corporation\MCEGold\Emax C:\PdMA Corporation\MCEGold\Report

#### Uninstall Older Versions of SQL Server

If any version of Microsoft SQL Server prior to Microsoft SQL Server 2017 (such as 2005, 2008, 2012, 2014, 2016, etc.) exists on your computer, proceed with the *Uninstall Older Versions of SQL Server* section followed by the *Uninstall Word Add-in* and *Uninstall MCEGold* sections below.

If only Microsoft SQL Server 2017 exists on your computer do not uninstall it and proceed to the section *Uninstall Word Add-in.* 

There are several components that begin with Microsoft SQL Server 20XX, they should all be removed starting with Microsoft SQL 2008 EXCEPT Microsoft SQL Server 2017.

1. Select Start, Settings, Apps.

- 2. Scroll down to locate Microsoft SQL Server 2008 from the list.
- 3. Highlight it and click Uninstall.
- 4. Follow the on-screen prompts.
- 5. Click **Finish** when the "Uninstall Complete" message is received. Do not close the window.
- 6. After uninstalling Microsoft SQL 2008, repeat from step 2, uninstalling all components that begin with Microsoft SQL Server 20XX. Reminder do not uninstall Microsoft SQL Server 2017 (or later)!
- Locate and uninstall all Microsoft System CLR Types for SQL Server prior to CLR type version 2017.
- 8. Repeat step 6 until all older CLR Types have been removed.
- 9. Do not close window.
- 10. Continue to Uninstall Word Add-in.

#### Uninstall Word Add-in

Note: If you have MCEGold Word Add-in installed, you need to uninstall it before upgrading to MCEGold 3.1.2 SP5.

- 1. Select Start. Settings, Apps.
- 2. Scroll down to locate MCEGold Word Add-in.
- 3. Highlight it and click Uninstall.
- 4. Follow the on-screen prompts.
- 5. Click **Finish** when the "Uninstall Complete" message is received.
- 6. Do not close the window.
- 7. Continue to Uninstall MCEGold.

#### Uninstall MCEGold

Note: If you have MCEGold icons pinned to your Taskbar, it is necessary to unpin them before beginning the uninstall. Right click on the icon and select "Unpin from taskbar".

1. Select Start, Settings, Apps.

- 2. Scroll down to locate MCEGold Version X.X.X.
- 3. Highlight it and click Uninstall
- 4. Follow the on-screen prompts.
- 5. Click **Finish** when the "Uninstall Complete" message is received.
- 6. Do not close the window.
- 7. If present locate the PdMA MCEMAX Tester (Driver Removal) file. Highlight it and click Uninstall and follow the on-screen prompts. If it is not present proceed to Step 7.
- 8. Click **Finish** when the "Uninstall Complete" message is received.
- Locate the C:\PdMA Corporation folder and delete it. The subfolders will be deleted also. After the installation of MCEGold 3.1.2 SP5 the new folder location will be C:\PdMA Corporation\....
- 10. Click **Finish** when the "Uninstall Complete" message is received.
- 11. Reboot the computer.
- 12. Continue to MCEGold 3.1.2 SP5 Installation.

## MCEGOLD 3.1.2 SP5 INSTALLATION

- 1. If installing on a tester, disconnect the USB cable from the tester computer.
- 2. Insert the MCEGold 3.1.2 SP5 USB flash drive into the USB port. If the installation does not begin automatically, run setup.exe from the USB flash drive. (Select Run, setup.exe from the AutoPlay window).
- 3. The License Agreement window opens. Read the PdMA license and select the "I Accept" option button. The **Next** button becomes visible. Click **Next**.

Note: If you do not accept the terms, the **Next** button is not visible, you can only click **Cancel**, which closes the software without installing it.

	PdMA <sup>®</sup> CORPORATION
MCEGold®	SOFTWARE LICENSING AGREEMENT
€20	13 PdMA Corporation, All Rights Reserved
	ion on the screen, you are confirming that you have read a copy of ent, and you agree to be bound by the terms of this Software
	DLD (Software) as part of your predictive maintenance applications.
	C   Do Not Accept

- 4. In the License Key window enter your Company Name and License Key <u>exactly</u> as provided by PdMA. You may copy and paste the license key using the paste button.
- 5. When the license has been verified a green check appears. The **Next** button appears. Click **Next**.
- 6. In the Installation Path window, accept the default shown in the text box (recommended) for the location to install the MCEGold program folder or use the browse (...) button to select an alternate location, make a note of it for your future use, and click **Next**. Note: It is not suggested to use an alternate location because that can cause conflict and Windows rights problems.
- 7. When prompted, click **Install Components**. Some components may require additional prompts.
- 8. When the installation of components is complete the **Next** button appears. Click **Next**.
- 9. A progress bar shows the progress of copying files to your computer.
- 10. When the installation is complete you must reboot your system. Select the Reboot Now option and click **Close**.

The MCEGold installation is complete. Some of the components require the syste Do you wish to reboot now?	m to be rebooted.
Reboot Now	C Reboot Later
	Close

11. After rebooting, locate and copy the backup Emaxprb.xml file and the Template folder back into their appropriate locations in

C:\PdMA Corporation\MCEGold\Emax C:\PdMA Corporation\MCEGold\Report

- 12. Answer Yes to "Merge the folder?" inquiry.
- 13. Remove the MCEGold 3.1.2 SP5 USB flash drive from the computer.
- 14. If installing on a tester, re-connect the USB cable to the tester computer.

## Upgrading From MCEGold 3.1.2 or Later

#### Backup

Before beginning the MCEGold installation copy the Emaxprb.xml file only (not the folder) and the complete Templates folder to a safe location and make note of the location.

The default location for the files is listed below, however you may have chosen a different location during the original installation.

C:\PdMA Corporation\MCEGold\Emax C:\PdMA Corporation\MCEGold\Report

#### Uninstall Older Versions of SQL Server

If any version of Microsoft SQL Server prior to Microsoft SQL Server 2017 (such as 2005, 2008, 2012, 2014, 2016, etc.) exists on your computer, proceed with the *Uninstall Older Versions of SQL Server* section followed by the *Uninstall MCEGold* section below.

If only Microsoft SQL Server 2017 exists on your computer do not uninstall it and proceed to the section *Uninstall Word Add-in*.

There are several components that begin with Microsoft SQL Server 20XX, they should all be removed starting with Microsoft SQL 2008 EXCEPT Microsoft SQL Server 2017.

- 1. Select Start, Settings, Apps.
- 2. Scroll down and locate Microsoft SQL Server 2008 from the list.

- 3. Highlight it and click Uninstall.
- 4. Follow the on-screen prompts.
- 5. Click **Finish** when the "Uninstall Complete" message is received. Do not close the window.
- 6. After uninstalling Microsoft SQL 2008, repeat from step 2, uninstalling all components that begin with Microsoft SQL Server 20XX. Reminder do not uninstall Microsoft SQL Server 2017 (or later)! Do not close the window.
- Locate and uninstall all Microsoft System CLR Types for SQL Server prior to CLR type version 2017.
- 8. Repeat from step 6 until all older CLR Types have been removed.
- 9. Click **Finish** when the "Uninstall Complete" message is received.
- 10. Close the Apps window when all components have been uninstalled.
- 11. Reboot the computer.

#### Uninstall Word Add-in


Note: If you have MCEGold Word Add-in installed, you need to uninstall it before upgrading to MCEGold 3.1.2 SP5.

- 1. Select Start, Settings, Apps.
- 2. Scroll down to locate MCEGold Word Add-in.
- 3. Highlight it and click Uninstall.
- 4. Follow the on-screen prompts.
- 5. Click **Finish** when the "Uninstall Complete" message is received.
- 6. Reboot the computer.
- 7. Continue to MCEGold 3.1.2 SP5 Installation.


#### MCEGold 3.1.2 SP5 Installation.

NOTE: Some on-screen prompts and messages during the installation process are controlled by the Windows operating system and are out of PdMA's control. Every effort has been made to include their possible appearance and the action you should take. However, if you are unsure please contact our technical support department for help at 813-621-6463 ext. 251.

- 1. If installing on a tester, disconnect the USB cable from the tester computer.
- 2. Insert the MCEGold 3.1.2 SP5 USB flash drive into the USB port. If the installation does not begin automatically, run setup.exe from the USB flash drive. (Select Run, setup.exe from the AutoPlay window).
- 3. If you see the User Account Control screen, click Yes..



4. If there is an existing MCEGold version installed on your computer, you will see the MCEGold Update screen. Click **Update**.



NOTE: If you have a version prior to MCEGold 3.1.2 you will receive the error message shown below. Do **NOT** proceed. Contact technical support.



5. The status update window displays.

athering file information. This r	nay take a rew minutes
Transferring file 46 of 706	
	Cancel
	Cancel

6. When the update is complete, click **Finish**.

athering file information. This may t	ake a rew minutesia
File update complete. Please click on the "Finish" button.	
riesse click of the Fillish botton.	

7. If the Program Compatibility Assistant screen displays, select *This program installed correctly*.

Program Compatibility Assistant	×
This program might not have installed corre	ectly
If this program didn't install correctly, try reinstalling usin are compatible with this version of Windows.	ng settings that
Program: Setup.exe Publisher: Macrovision Corporation Location: C:\MCEGold Builds\V3.0.3-SP3 - D	VD R\setup.exe
😵 Reinstall using recommended settings	
<ul> <li>This program installed correctly</li> </ul>	
	Cancel
What settings are applied?	

8. If installing on a tester, re-connect the USB cable to the tester computer.

9. Continue to the *Database Setup* section.

## DATABASE SETUP

**Note:** This procedure is for connecting to an existing database that is to be upgraded to MCEGold 3.1.2 SP5. To connect to an existing database, please follow the instructions below.

- 1. Ensure you have properly backed up the database you are converting.
- 2. Open the Utility program and click the **Database** button.

MCEGold Utility : Marathon Pipeline LLC					
Version: Stand Alone					
License Key Update MCEGold License Linformation	tion Information	Installation Infor	mation		
Database Database Database Tesks related to the MCEGod Detabase.					
	Main	Back	Exit		

3. Click Attach DB as shown in the screen below.

ACEGold Utility : Marathon Popeline LLC Database Database Options  Crease new database	Next
Local database Attach the local database Database cath	Attach D8
Diagnostic tools / Local database editor	Diagnostics Local Editor Main Back Exit

4. Navigate to the database location on your computer and select the desired database.


If you receive the following message: "The database you selected was created with an older SQL version", the database needs to be upgraded to SQL 2017. **Stop!** Click **No.** Do **NOT** proceed! Contact Technical Support.

-	_			
0		tabase was created database will upgrad		
	be able to be at	tached to an older S	QL Server.	
	Do you wish to	attach this database	er -	

5. If the database attached properly you will see the following window. Click **OK**.

MCEGold	×
🚺 Dat	base has been attached successfully
	ОК

6. The MCEGold Utility Database Window opens. Click Exit.



## START MCEGOLD

- 1. Start MCEGold.
- 2. If the database window is empty, select a database using the Search button (...) located on the right side of the Site textbox. This opens your computer

navigator window which allows you to search for a database. When the database has been selected, click **Open**.


3. Verify login parameters on the right side of the window are correct and click **OK**.

NOTE: If no databases are available, click **Cancel** to exit out of MCEGold, and contact PdMA Technical Support at 813-621-6463 ext. 251.

If you receive the following message: "The database you selected was created with an older SQL version", the database needs to be upgraded to SQL 2017. **Stop!** Click **No**. Do **NOT** proceed! Contact Technical Support.



If you receive the following "The local database is not supported by this update" message, the attached database is too old for conversion and needs to be updated to MCEGold 3.0.3 SP2 or later prior to updating to MCEGold 3.1.2 SP5. Contact your system administrator.



If you receive the following "Incompatible Database Version" message when trying to start MCEGold, you are attempting to run MCEGold with a database that is older than MCEGold 3.1.2. You will be prompted to update the database. If you have properly backed up your existing database, click **Yes** to run the update. If you have not backed up your existing database, click **No**, backup the database, and then perform the Database Setup procedure.

NOTE: Please make sure you allow sufficient time to update your database.

Incompat	tible Database Version	X
1	The local database you are attempting to connect to is an older version than the current MCEGold installed. A database update is required to run this database on this version of MCEGold. Running the update will make the database incompatible with older versions of MCEGold. Do you wish to run this update?	
	Yes No	