



A Leader in Electric Motor Testing

Tip Of The Week

January 12, 2015

This Battery Looks Different

You have just received your new M-Series tester and when taking inventory you notice that the battery and installation compartment have been completely re-designed. The new PdMA M-Series tester utilizes the latest in Smart Lithium-ion (Li-ion) technology giving you a 400% increase in battery capacity, plus there is no longer a need to periodically put the battery through a discharge routine. Your Li-ion battery comes with an on-board push button fuel gauge to show you how much charge is on the battery. For example, if all four green LED's are illuminated you are between 76-100% charge. And now with the Smart battery technology there is an additional fuel gauge located in the MCEGold[®] software that communicates with the Li-ion battery to give you a very accurate available capacity remaining on the battery. One last thing to remember - to ensure a long battery life when your battery is not in use it is important to store it at room temperature and perform a charge if it has less than a 50% charge.

To find out more benefits of the M-Series MCEMAX[®] please view this short video:
http://www.pdma.com/webinars/M_Series/PDMA_video_v2.mp4

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA[®] mug or hat if we publish it! Contact Lou at 813-621-6463 ext. 126 or lou@pdma.com.

Copyright 2014 PdMA[®] Corporation. All rights reserved. The PdMA Tip of the Week is produced by PdMA. PdMA shall not be liable for any errors or delays in the content, or for any actions taken in reliance thereon.